


1 Fit clamp to desk surface


2 Install bottom jaw in correct location using screws provided (for non-screened desks this can be pre-installed)



3 Insert screw, place pad on top and tighten screw under work surface

4 Install cover by pushing locating bosses into holes in the desk clamp before mounting the post

Maximum Desk Thicknesses



WARNING

- Do not use this product for any purpose other than that for which it was designed
- Ensure desk/work surface is suitable to take the weight of the arm/s and monitors
- Supported weight must not exceed the maximum load per arm
- Take care when installing as fingers could become trapped

MAINTENANCE and INSPECTION

- Ensure all screws are tightened and occasionally adjust if needed
- Ensure post is fully tightened to the clamp before installing the arm and monitor
- Clean with a damp cloth, NO solvents

DISCLAIMERS

- The use of power tools, lever bars or excessive force during the installation, or re-configuration of the product will invalidate your guarantee
- Failure to observe the recommendations in the use, and configuration of these products may affect your guarantee

UNI-SMC-01-INST-A FEB2012

www.colebrookbossonsaunders.com