



High load top mount clamp

UNI/HLC/002


- 1 Position clamp plate and clamp pad on desk close to the edge (approx. 5mm)



- 2 Attach spacer pad to C-bracket in required orientation




- 3 Pass C-bracket and spacer around work surface. Ensure inside of bracket is flush against the work surface. Locate screws into clamp plate




- 4 Tighten clamp screws

⚠ Ensure screws are fully tightened



- 5 Fit the clamp cover



WARNING

- Do not use this product for any purpose other than that for which it was designed
- Ensure desk/work surface is suitable to take the weight of the arm/s and monitors
- Supported weight must not exceed the maximum load per arm
- Take care when installing as fingers could become trapped

MAINTENANCE AND INSPECTION

- Ensure all screws are tightened and occasionally adjust if needed
- Ensure post is pushed fully down onto clamp plate before installing the arm and monitor
- Clean with a damp cloth, No solvents

DISCLAIMERS

- The use of power tools, lever bars or excessive force during the installation, or re-configuration of the product will invalidate your guarantee
- Failure to observe the recommendations in the use, and configuration of these products may affect your guarantee

UNI/HLC/002 INST-A FEB2014