




- 1 Place the top mount clamp plate on desktop
- 2 Fit spacer onto clamp bracket and fit around the workspace



- 3 Insert screws into clamp bracket aligning them with the holes on the clamp plate and tighten



- 4 Fit cap onto clamp before mounting the post



DO NOT attach the post before fully assembling the clamp onto the desk

⚠ WARNING

- Do not use this product for any purpose other than that for which it was designed
- Ensure desk/work surface is suitable to take the weight of the arm/s and monitors
- Supported weight must not exceed the maximum load per arm
- Care should be taken to avoid trapping fingers

⚠ MAINTENANCE and INSPECTION

- Ensure all screws are tightened and occasionally adjust if needed
- Ensure post is fully tightened to the clamp before installing the arm and monitor
- Clean with a damp cloth, NO solvents

⚠ DISCLAIMERS

- The use of power tools, lever bars or excessive force during the installation, or re-configuration of the product will invalidate your guarantee
- Failure to observe the recommendations in the use, and configuration of these products may affect your guarantee

UNI-TAC-01-INST-A FEB2012

www.colebrookbossonsaunders.com